



LIBERTY PATCH
Subli BLOCK SUB



DATA SHEET

email : contact@walternash.ie

site : www.walternash.ie

Date: 08/10/2021

PRODUCT		Printable TEXTILE film (indirect printing with SUBLIMATION transfer paper) for heat transfer on any sublimated polyester
CODE	S901 TBS	box of 50 sheets A4 or A3 or in rolls
DESCRIPTION	Printable Polyester TEXTILE with heat-adhesive (indirect printing with SUBLIMATION transfer paper) on self-adhesive polyester carrier suitable to sublimated polyester textiles. A BLOCKSUB barrier prevents resublimation	
THICKNESS +/-5%	Polyester textile: 380µ	Low tack adhesive polyester carrier: 120µ
TEXTILES	Cotton - Polyester - Polycotton - Nylon (to be tested before use).	
ADVANTAGES	<ol style="list-style-type: none"> 1. Thick and opaque textile with a FABRIC visual and touch and a total bareer to resublimation 2. Ideal for badges, professional, sports and fashion clothes 3. Freedom to create any badges from photos, with small letterings, with gradient, endless colors, complex patterns 4. High Washing resistance up to 40°C 5. A professional quality with vibrant colors 6. Suitable to any types of sublimation inks 7. Possibility to cut out the contours thanks to a plotter with an optical eye function, also with laser cutting 8. Universal thermoadhesive with excellent proven bonding on most textiles 9. Ecofriendly, water based, solvent and PVC free polyurethane, textile woven in France 10. Low carbon profile manufacturing: all operations made under one roof 11. 100% made in France, out of european raw materials. 12. Last generation machines and exclusive manufacturing process 	
USER'S GUIDE	<ol style="list-style-type: none"> 1. With a sublimation printer, print in mirror on sublimation paper with the crop marks (also in mirror) 2. Transfer your printed visual from the sublimation paper to Liberty Patch Subli with a heat press at 190°C-50 secondes. Hot peel 3. You can cut out the contours of Liberty Patch Subli Blocksub with scissors or thanks to a plotter with an optical eye function. Set up the blade to cut only the print film, and not the carrier, then weed. 4. Then put the visual (separated from the carrier) on textile, so you can see the visual, protect it with baking paper and press at 140°C -5 seconds (adapt temperature and time according to textile) Hot Peel 	
WASHING TEMPERATURE	up to 40°C	
FURTHER RECOMMENDATIONS	<ol style="list-style-type: none"> 1. Wait 24 hours before washing. 2. Do not use bleach or other aggressive chemical agents. 3. Iron from inside. 4. Store our products in a tempered and dry room, protected from direct sun rays. 5. In order to prevent resublimation, it is recommended, NOT to preheat garments. 6. Just after heat transfer, DO NOT stack or fold warm garments, as this could cause resublimation on the external side of the Flex material. 	
SAFETY	Inert components, REACH compliant, without PVC, plastifiers, heavy metals, VOC, according to Oekotex Standard 100 Class 1.	

This document is likely to be modified without notice. Please take contact with our commercial department.